



**GUITARS
AMPLIFIERS
ACCESSORIES**

TELECASTER DELUXE
Solid Body Guitar,
2 Humbucking P.U.,
Maple Neck, 2 separate
Tone- and Vol.-Controls
Standard: Walnut
Special: sunburst, black,
blond, natural



TELECASTER BASS
Solid Body Bass,
1 Humbucking P.U.
Standard: blond
Special: colors



TELECASTER-THINLINE
Semi-acoustic guitar,
2 Humbucking P.U.,
Standard: sunburst, ash
Special: colors, tremolo



TELECASTER
Solid Body Guitar,
2 P.U.
Standard: blond
Special: colors
and/or maple neck,
bigsby tremolo

TELECASTER CUSTOM
Solid Body Guitar,
1 normal P.U. lead
1 Humbucking P.U.
Standard: sunburst
Special: Walnut, blond,
black, natural and/or
maple neck



CBS/ARBITER LIMITED

Fender House
Centenary Estate
Jeffreys Road Brimsdown
Enfield Middx
Tel. 01-805 8555, Telex 299465
England

CBS/ARBITER GmbH

Emanuel-Leutze-Straße 1
4000 Düsseldorf
Tel. 0211/593039
West-Germany



MUSICMASTER

Solid Body Guitar, 1 - P.U.
Standard: white, red, blue



STARCASTER

Semi-Acoustic/Thinline
Cutaway Body, 2 Humbucking
P.U. Maple Neck
Colors: T-sunburst, white, black
natural, walnut



MUSICMASTER BASS

Solid Body Bass, 1 - P.U.
Standard: red, white, blue



JAZZMASTER

Solid Body Guitar, 2 P.U. - Tremolo
Standard: sunburst



STRATOCASTER

Solid Body Guitar, 3 P.U. - Tremolo
Standard: sunburst
Special: colors and/or maple neck



JAGUAR

Solid Body Guitar, 2 P.U. - Tremolo
Standard: sunburst



PRECISION BASS

Solid Body Bass, 1 - split - P.U.
Standard: sunburst
Special: colors and/or maple neck



JAZZ BASS

Solid Body Bass, 2 - P.U.
Standard: sunburst
Special: colors and/or maple neck



CHAMP
1 x 8" Fender Speaker
6 RMS - 12 Watts Peak



VIBRO-CHAMP
1 x 8" Fender Speaker
6 RMS - 12 Watts Peak Vibrato



PRINCETON
1 x 10" Fender Speaker
12 RMS - 20 Watts Peak



PRINCETON/REVERB
1 x 10" Fender Speaker
12 RMS - 20 Watts Peak Reverb, Vibrato



DELUXE/REVERB
1 x 12" Fender Speaker
20 RMS - 44 Watts Peak Reverb, Vibrato



VIBROLUX/REVERB
2 x 10" Fender Speakers
40 RMS - 80 Watts Peak Reverb, Vibrato



PRO/REVERB
2 x 12" Fender Speakers
80 RMS - 100 Watts Peak Reverb, Vibrato




SUPER/REVERB
4 x 10" Fender Speakers
45 RMS - 100 Watts Peak Reverb, Vibrato
Special: 4 x D 110 F JBL Speakers



TWIN/REVERB
2 x 12" Fender Speakers
100 RMS - 200 Watts Peak Reverb, Vibrato
Special: 2 x D 120 F JBL Speakers



QUAD/REVERB
4 x 12" Fender Speakers
100 RMS - 200 Watts Peak Reverb, Vibrato
Special: 4 x D 120 F JBL Speakers



SUPER SIX/REVERB
6 x 10" Fender Speakers
180 RMS - 300 Watts Peak Reverb, Vibrato
Special: 6 x D 110 F Speakers



BANDMASTER/REVERB
2 x 12" Fender Speakers
45 RMS - 100 Watts Peak Reverb, Vibrato
Special: 2 x D 120 F JBL Speakers




BASSMAN 50
2 x 15" Fender Speakers
50 RMS - 115 Watts Peak
Special: 2 x D 140 F JBL
Speakers



BASSMEN TEN
4 x 10" Fender Speakers
50 RMS - 110 Watts Peak
Special: 4 x D 110 F JBL
Speakers



BASSMAN 100
4 x 12" Fender Speakers
100 RMS - 220 Watts Peak



DUAL/SHOWMAN REVERB
2 x 15" D 135 F Speakers
100 RMS - 220 Watts Peak
Reverb, Vibrato
Special: 2 x D 140 F JBL
Bass Speakers



VIBROSONIC/REVERB
1 x 15" PS - Speaker
100 RMS - 220 Watts Peak
Reverb, Vibrato



PIANO-BASS
30-Keys, Full Bass Sound
with Controls
Extra: Stand




FENDER-BLENDER
Fuzz and Sustain Unit,
Tone, Volume Controls
for Bass, Guitar and Piano



MUSICMASTER BASS AMP
1 x 12" Fender Speaker
12 RMS - 28 Watts Peak



SUPER-TWIN
2 x 12" Fender Super-Power Speakers
160 RMS - 385 Watts Peak



SUPER-SATELLITE POWER-SPEAKERS
Ideal for Mark I Stage Piano

2 Boxes with 2 x 12" Fender Speakers each. Stereo Effect.
100 RMS - 220 Watts Peak per Box.
Total output 400 Watts. Pre-Amp to build into Stage Piano



SUITCASE PIANO
88 or 73-Keys. Portable, built in:
Volume and Tone Controls, Vibrato and Sustain Pedal.
4 x 12" Fender Speakers 80 RMS - 100 Watts Peak



MARK I STAGE PIANO
88 or 73-Keys. Portable. Volume and Tone Controls.
No Amplifier



PA-100 Vocal Sound System
8x8" Fender Speakers

100 RMS - 220 Watts Peak - 4 Channels - 8 Inputs
Extras: Chrome Stand, High Frequency Horns



FENDER PICKS

305

348

351

354

358

PART NO.



351 Thin - Shell - Gross	99-1629
351 Medium - Shell - Gross	99-1630
351 Heavy - Shell - Gross	99-1631
351 Thin - White - Gross	99-1625
351 Medium - White - Gross	99-1626
351 Heavy - White - Gross	99-1627
358 Thin - Shell - Gross	99-1725
358 Medium - Shell - Gross	99-1726
358 Heavy - Shell - Gross	99-1727
358 Thin - White - Gross	99-1629
358 Medium - White - Gross	99-1630
358 Heavy - White - Gross	99-1631
348 Thin - White - Gross	99-2125
348 Medium - White - Gross	99-2126
348 Heavy - White - Gross	99-2127
354 Thin - White - Gross	99-2525
354 Medium - White - Gross	99-2526
354 Heavy - White - Gross	99-2527
355 Thin - Shell - Gross	99-5225
355 Medium - Shell - Gross	99-5226
355 Heavy - Shell - Gross	99-5227




FENDER PICK DISPLAY CARDS

PART NO.

351 Thin - Shell - Card	99-2225
351 Medium - Shell - Card	99-2226
351 Heavy - Shell - Card	99-2227



300 PS GUITAR AMP
 4 x 12" Speakers - 300 Watts RMS-600 PEAK
 Equalizer - (Stand extra)



300 PS BASS AMP
 4 x 12" Bass-Speakers - 300 Watts RMS-600 PEAK
 Equalizer - (Stand extra)